

Loft Area

Coax from outside coupled directly to working coax cable going to outlet behind TV on main level. None of the cables have identifying marks. Items connecting this cable to outside coax line have "RS59LMG" on metal couplers.

TV

Main Level

Coax into home

Hanging coax cable strung to wall-mounted TV; connected to unused splitter, not to TV

Hanging coax cable likely to loft wall outlet

router

modem

TV

TV

Coax cable to be strung to TV

Wood block

4-Way old splitter that is not connected (Channel Master Model 7394: 5-900 MHz)

Basement

Den

TV

